

Spare part №	Description
69027344	A PUMP
234912	A PUMP
4698565	A PUMP & VALVE
243680	A PUMP & VALVE
75285037	A PUMP 15 GAL M
237088	A PUMP 15 GAL M
4697619	A PUMP DR SLEEV
4698613	A PUMP DR SLEEV
233250	A PUMP DR SLEEV
239640	A PUMP DR SLEEV
840765200	A PUMP DR SLEEV
4694041	A PUMP DRIVE AS
240733	A PUMP DRIVE AS
S97384	A PUMP SLVE
230234	A PUMP SLVE
4698315	A PUMP SLVE
64803683	A PUMP SLVE
841233000	A PUMP SLVE
232407	A PUMP SLVE
4691309	ASSY — PUMP
250228	ASSY — PUMP
75285841	ASSY CHARGE PUMP
249345	ASSY CHARGE PUMP
4697504	ASSY CHARGE PUMP
F026179	ASSY CHARGE PUMP
291523A1	ASSY CHG PUMP
4203850	ASSY CHG PUMP
471319493	ASSY CHG PUMP
250387	ASSY CHG PUMP
55014753	ASSY. CHARGE PUMP
246495	ASSY. CHARGE PUMP
55026538	ASSY. -CHARGING PUMP
250388	ASSY. -CHARGING PUMP
11700742	ASSY. FRNT. PUMP
249819	ASSY. FRNT. PUMP
55026872	ASSY. PUMP & COVER
843140200	ASSY. PUMP & COVER
249657	ASSY. PUMP & COVER
56019071	ASSY. PUMP & REG. VALVE
M0244220	ASSY. PUMP & REG. VALVE
244220	ASSY. PUMP & REG. VALVE
69036594	ASSY.-VALVE & PUMP
250389	ASSY.-VALVE & PUMP
4691126	ASSY-CHRG PUMP
843080000	ASSY-CHRG PUMP
249584	ASSY-CHRG PUMP
214351	ASSY-OIL PUMP DRIV

4698121	ASSY-PUMP DRIVE SHFT
238128	ASSY-PUMP DRIVE SHFT
71008981	ASSY-PUMP DRIVE SLEEVE & SNAP RING
73066756	ASSY-PUMP DRIVE SLEEVE & SNAP RING
4698267	ASSY-PUMP DRIVE SLEEVE & SNAP RING
840880200	ASSY-PUMP DRIVE SLEEVE & SNAP RING
840765200	ASSY-PUMP DRIVE SLEEVE & SNAP RING
M0236292	ASSY-PUMP DRIVE SLEEVE & SNAP RING
31901008	ASSY-PUMP DRIVE SLEEVE & SNAP RING
31901218	ASSY-PUMP DRIVE SLEEVE & SNAP RING
233250	ASSY-PUMP DRIVE SLEEVE & SNAP RING
236292	ASSY-PUMP DRIVE SLEEVE & SNAP RING
31905240	ASSY-PUMP/FILTER
251795	ASSY-PUMP/FILTER
4697503	ASSY-PUMP/FILTER
56020303	ASSY-PUMP/FILTER
11700743	BRAKE PUMP SECT
249820	BRAKE PUMP SECT
3261141	BRG-PUMP SHAFT
860668	BRG-PUMP SHAFT
55025625	CHARGE PUMP
238913	CHARGE PUMP
251314	CHARGE PUMP
	CHARGING PUMP
541338	CHARGING PUMP
59015615	CHARGING PUMP
59020034	CHARGING PUMP
59016693	CHARGING PUMP
S217796	CHARGING PUMP
238243	CHARGING PUMP
4207785	CHARGING PUMP
4205949	CHARGING PUMP
251314	CHARGING PUMP
251793	CHARGING PUMP
55076870	CHARGING PUMP
4700131	CHARGING PUMP
56013087	CHARGING PUMP
M12973355	CHARGING PUMP
237231	CHARGING PUMP
247026	CHARGING PUMP
4698112	CHARGING PUMP A
237462	CHARGING PUMP A
246317	CHARGING PUMP KIT
8100076	CHARGING PUMP KIT
U-450230	CHARGING-PUMP
450230	CHARGING-PUMP
4698321	CHG PUMP
239697	CHG PUMP

4699353	CHG PUMP ASSY
237546	CHG PUMP ASSY
238912	CHG PUMP ASSY11
238913	CHG PUMP ASSY11
A47838	CHG PUMP ASSY11 (OBSOLETE)
238913	CHG PUMP ASSY11 (OBSOLETE)
4698127	CHG PUMP&AUX PU
239679	CHG PUMP&AUX PU
4691123	COVER-PUMP
841716700	COVER-PUMP
F432201	COVER-PUMP
248846	COVER-PUMP
3614624	COVER-PUMP
4699826	GASKET-PUMP COV
473003869	GASKET-PUMP COV
238116	GASKET-PUMP COV
F432765	GEAR PUMP DRIVE
F432757	GEAR PUMP DRIVE
F432719	GEAR PUMP DRIVE
250214	GEAR PUMP DRIVE
250213	GEAR PUMP DRIVE
248655	GEAR PUMP DRIVE
F004063	GEAR- PUMP SHAFT
242488	GEAR- PUMP SHAFT
73118081	GEAR-CHARGING PUMP DRIVE
F004222	GEAR-CHARGING PUMP DRIVE
31901391	GEAR-CHARGING PUMP DRIVE
236584	GEAR-CHARGING PUMP DRIVE
238212	GEAR-CHARGING PUMP DRIVE
843055000	GEAR-PUMP
F432716	GEAR-PUMP
248947	GEAR-PUMP
248654	GEAR-PUMP
73131723	GEAR-PUMP DRIVE
79030242	GEAR-PUMP DRIVE
4696629	GEAR-PUMP DRIVE
31901392	GEAR-PUMP DRIVE
U-214931	GEAR-PUMP DRIVE
214931	GEAR-PUMP DRIVE
236585	GEAR-PUMP DRIVE
843050600	GEAR-PUMP DRIVE
843096100	GEAR-PUMP DRIVE
F432713	GEAR-PUMP DRIVE
248903	GEAR-PUMP DRIVE
249580	GEAR-PUMP DRIVE
248656	GEAR-PUMP DRIVE
71004756	GEAR-PUMP DRIVE 47T
4698252	GEAR-PUMP DRIVE 47T

F026156	GEAR-PUMP DRIVE 47T
T50554	GEAR-PUMP DRIVE 47T
470023453	GEAR-PUMP DRIVE 47T
31901006	GEAR-PUMP DRIVE 47T
230812	GEAR-PUMP DRIVE 47T
4699818	GRP-PUMP DR SLV
841434900	GRP-PUMP DR SLV
CB01409668	GRP-PUMP DR SLV
11704783	GRP-PUMP DR SLV
240762	GRP-PUMP DR SLV
56002140	HOUSING — PUMP
233672	HOUSING — PUMP
73118166	KIT-CHARGING PUMP
790519076	KIT-CHARGING PUMP
79051076	KIT-CHARGING PUMP
31901333	KIT-CHARGING PUMP
8100149	KIT-CHARGING PUMP
8100134	KIT-CHARGING PUMP
F004213	KIT-CHARGING PUMP
11713099	KIT-CHARGING PUMP
4695731	KIT-service kit /charging pump
8100076	KIT-service kit /charging pump
745821	OIL PUMP
4210754	OIL PUMP
4698957	OIL PUMP DR GR
219171	OIL PUMP DR GR
814458	PUMP
	PUMP
DG4212354	PUMP
550424	PUMP
449418	PUMP
514668	PUMP
527782	PUMP
560641	PUMP
59007455	PUMP
78344000	PUMP
59003543	PUMP
59016539	PUMP
SA8320-12430	Pump
31901745	PUMP
4212354	PUMP
246449	PUMP
235821	PUMP
235831	PUMP
244223	PUMP
238122	PUMP
238241	PUMP
251266	PUMP

8100076	Pump
238244	PUMP
73118166	PUMP
64107202	PUMP
4697333	PUMP
4698050	PUMP
3260952	PUMP
4693879	PUMP
4697942	PUMP
56019065	PUMP
64803768	PUMP
841903800	PUMP
F120801	PUMP
237567	PUMP
238242	PUMP
238243	PUMP
251267	PUMP
250311	PUMP
S89543	PUMP ADAPTER
362140A1	PUMP ADAPTER
216388	PUMP ADAPTER
4205241	PUMP ADAPTER
301875	PUMP ADAPTER
56039322	PUMP ADAPTER
64114134	PUMP ADAPTER
228194	PUMP ADAPTER
79064461	PUMP ADAPTOR
4693875	PUMP ADAPTOR
4694040	PUMP ADAPTOR
4698278	PUMP ADAPTOR
840782000	PUMP ADAPTOR
228666	PUMP ADAPTOR
237354	PUMP ADAPTOR
237420	PUMP ADAPTOR
240731	PUMP ADAPTOR
N8146	PUMP ADAPTOR (OBS)
237354	PUMP ADAPTOR (OBS)
4693648	PUMP ADPTR
231727	PUMP ADPTR
239233	PUMP ASSEMBLY
4699446	PUMP ASSM15
841161500	PUMP ASSM15
238122	PUMP ASSM15
75206073	PUMP ASSM21
4698860	PUMP ASSM21
238135	PUMP ASSM21
4695579	PUMP ASSM31
238117	PUMP ASSM31

79051076	PUMP ASSY
31901333	PUMP ASSY
237454	PUMP ASSY
843080000	PUMP ASSY
11999587-6	PUMP ASSY
268613	PUMP ASSY
249263	PUMP ASSY
4693876	PUMP ASY
237454	PUMP ASY
79051076	PUMP ASY
79051076	PUMP ASY (R/B 8100134)
237454	PUMP ASY (R/B 8100134)
4698108	PUMP BODX& ADAP
237461	PUMP BODX& ADAP
4698120	PUMP BODY
4698863	PUMP BODY
4699889	PUMP BODY
55016769	PUMP BODY
842041600	PUMP BODY
238123	PUMP BODY
238131	PUMP BODY
234839	PUMP BODY
250222	PUMP BODY
COL223124	PUMP COVER
4699487	PUMP COVER
223124	PUMP COVER
73131720	PUMP COVER GA
814271	PUMP COVER GA
841162000	PUMP COVER GA
223125	PUMP COVER GA
4697422	PUMP DISCONNECT
CB01409660	PUMP DISCONNECT
247116	PUMP DISCONNECT
233723	PUMP DR COUPLIN
4693848	PUMP DR GEAR N1
241920	PUMP DR GEAR N1
237167	PUMP DR GEAR N1
D87167	PUMP DR SHAFT
237548	PUMP DR SHAFT
3260452	PUMP DR SHAFT
4699478	PUMP DR SHAFT
841161100	PUMP DR SHAFT
239639	PUMP DR SLEEVE
4697405	PUMP DR. SHAFT
M12973659	PUMP DR. SHAFT
247714	PUMP DR. SHAFT
55016778	PUMP DRIVE ADAP
MO219883	PUMP DRIVE ADAP

219883	PUMP DRIVE ADAP
S300133	PUMP DRIVE ASSY
234824	PUMP DRIVE ASSY
3260504	PUMP DRIVE GEAR
4693661	PUMP DRIVE GEAR
4697411	PUMP DRIVE GEAR
4697421	PUMP DRIVE GEAR
841950900	PUMP DRIVE GEAR
T50539	PUMP DRIVE GEAR
11704672	PUMP DRIVE GEAR
231905	PUMP DRIVE GEAR
233227	PUMP DRIVE GEAR
247715	PUMP DRIVE GEAR
240437	PUMP DRIVE GEAR
73131729	PUMP DRIVE SHAFT
841161100	PUMP DRIVE SHAFT
31901706	PUMP DRIVE SHAFT
237548	PUMP DRIVE SHAFT
N8145	PUMP DRIVE SLEE
236291	PUMP DRIVE SLEE
4694044	PUMP DRIVE SLEE
T58545	PUMP DRIVE SLEE
240761	PUMP DRIVE SLEE
4698111	PUMP DRIVESHTFA
237419	PUMP DRIVESHTFA
4700589	PUMP DRV GEAR N
11704872	PUMP DRV GEAR N
222037	PUMP DRV GEAR N
243756	PUMP DRV GEAR N
4693856	PUMP GEAR
F004033	PUMP GEAR
M0237276	PUMP GEAR
237276	PUMP GEAR
240438	PUMP GEAR
S97379	PUMP GEAR N1
229784	PUMP GEAR N1
4700972	PUMP GEAR N1
F004031	PUMP IDLER GEAR
240434	PUMP IDLER GEAR
4694559	PUMP KIT
802174	PUMP KIT
4694558	PUMP KITS
802173	PUMP KITS
4692027	PUMP MTG SCREW
4700595	PUMP MTG SCREW
810695700	PUMP MTG SCREW
1C772	PUMP MTG SCREW
1C722	PUMP MTG SCREW

4697307	PUMP MTG. ADAPT
232402	PUMP MTG. ADAPT
4697170	PUMP SHAFT
841952600	PUMP SHAFT
M0245886	PUMP SHAFT
245886	PUMP SHAFT
240441	PUMP SHAFT
4694034	PUMP SHAFT GEAR
240442	PUMP SHAFT GEAR
64117852	PUMP SLEEVE
841429600	PUMP SLEEVE
T50545	PUMP SLEEVE
229782	PUMP SLEEVE
233229	PUMP SLEEVE
4699354	PUMP&ADAPTOR AS
842589800	PUMP&ADAPTOR AS
237547	PUMP&ADAPTOR AS
S217796	PUMP-ASSM ( R/B 251314)
450230	PUMP-ASSM ( R/B 251314)
450229	PUMP-ASSM11G-3
4700864	PUMP-ASSM15G-3
450230	PUMP-ASSM15G-3
D73724	PUMP-ASSM15G-4
D73725	PUMP-ASSM15G-4
31905041	PUMP-ASSM15G-4
234639	PUMP-ASSM15G-4
234659	PUMP-ASSM15G-4
71016522	PUMP-ASSM15G-4
73066787	PUMP-ASSM15G-4
4693800	PUMP-ASSM15G-4
4697503	PUMP-ASSM15G-4
4697504	PUMP-ASSM15G-4
235951	PUMP-ASSM15G-4
M0234659	PUMP-ASSM15G-4
4697615	PUMP-ASSM20
237350	PUMP-ASSM20
75285841	PUMP-ASSM-20-4
31905219	PUMP-ASSM-20-4
235045	PUMP-ASSM-20-4
4698270	PUMP-ASSM-20-4
4698272	PUMP-ASSM-20-4
F026179	PUMP-ASSM-20-4
840785400	PUMP-ASSM-20-4
AT52469	PUMP-ASSM-20-4
470023139	PUMP-ASSM-20-4
234829	PUMP-ASSM-20-4
73132362	PUMP-ASSM21G-2
301841	PUMP-ASSM21G-2



4700837	PUMP-ASSM21G-2
233297	PUMP-ASSM21G-2
450245	PUMP-ASSM21G-2
S224257	PUMP-ASSM21G-2(use 251266)
450245	PUMP-ASSM21G-2(use 251266)
4699503	PUMP-ASSM31
238110	PUMP-ASSM31
4697942	PUMP-ASSM31G-2
450246	PUMP-ASSM31G-2
31901129	PUMP-CHARGING
4206814	PUMP-CHARGING
73132362	PUMP-CHRG
251266	PUMP-CHRG
4700837	PUMP-CHRG
12974780	PUMP-CON. CHRG.
240730	PUMP-CON. CHRG.
4696706	PUMPDRIVE SHFTA
4698118	PUMPDRIVE SHFTA
4699890	PUMPDRIVE SHFTA
842041700	PUMPDRIVE SHFTA
238126	PUMPDRIVE SHFTA
239678	PUMPDRIVE SHFTA
237545	PUMPDRIVE SHFTA
238484	PUMPDRIVE SHFTA
F432974	Pumps
471395347	Pumps
11704622	Pumps
250127	Pumps
000233372000 S03	Pumps
75285796	Pumps (R/B 8100180)
246343	Pumps (R/B 8100180)
217959	SHAFT PUMP
73118262	SUPPORT-PUMP DRIVE BEARING
31901375	SUPPORT-PUMP DRIVE BEARING
31904148	SUPPORT-PUMP DRIVE BEARING
234327	SUPPORT-PUMP DRIVE BEARING
4205121	SUPPORT-PUMP DRIVE BEARING